


# **OPERATION & SERVICE MANUAL**



Model: 01-1286-0000 Premier Portable Snap-Bak Towbar



02/2007 - Rev. 02

For Spare Parts, Operations & Service Manuals or Service Needs Scan the QR code or visit Tronair.com/aftermarket



REVISION 02 DATE 03/2007 TEST AFFECTED Major Revision



## **TABLE OF CONTENTS**

		<u>PA</u>	\GE	
1.0	PROD	UCT INFORMATION	1	
	1.1	DESCRIPTION		
	1.2	MODEL & SERIAL NUMBER	1	
	1.3	MANUFACTURER	1	
	1.4	SPECIFICATIONS	1	
2.0	SAFET	TY INFORMATION	1	
	2.1	GENERAL	1	
3.0	TRAINING			
	3.1	TRAINING REQUIREMENTS	2	
	3.2	TRAINING PROGRAM	2	
	3.3	OPERATOR TRAINING		
4.0	OPERATION			
	4.1	TOWBAR CHECKLIST		
	4.1.1	Towbar		
	4.1.2	Towing Head		
	4.2	USAGE PROCEDURE		
	4.2.1	Aircraft Attachment	2	
	4.2.2	Tug Attachment		
	4.2.3	Couplers	3	
	4.2.4	Towing Operation		
5.0	PROVISION OF SPARES			
	5.1	SOURCE OF SPARE PARTS	4	
	5.2	RECOMMENDED SPARE PARTS LISTS		
6.0		RVICE SUPPORT		
7.0		ANTEES/LIMITATION OF LIABILITY		
8.0	APPEN	NDICES	4	



Model: 01-1286-0000 Premier Portable Snap Bak Towbar



Tronair towbars/heads must only be used with matching Tronair heads/towbars, and Tronair shear pins.

This product can not be modified without the written approval of Tronair, Inc. Any modifications done without written approval voids all warranties and releases Tronair, Inc., it suppliers, distributors, employees, or financial institutions from any liability from consequences that may occur. Only Tronair OEM replacement parts shall be used.

### 1.0 PRODUCT INFORMATION

### 1.1 DESCRIPTION

The Tronair Model 01-1286-0000 Snap-Bak Towbar is a lightweight, portable towbar for the Premier Aircraft manufactured by Raytheon.

The snap-bak towbar includes a spring in the towing head attachment to the towbar which provides a dampening of radial forces about the aircraft nose landing gear during towing operation. The aircraft attachment is by machined pins on the towing head to the nose landing gear axle. There is a handle and an eyebolt at the end of the towbar for towing.

### 1.2 MODEL & SERIAL NUMBER

Reference nameplate on unit

### 1.3 MANUFACTURER

**TRONAIR**, Inc. Telephone: (419) 866-6301 or 800-426-6301

1 Air Cargo Pkwy East Fax: (419) 867-0634
Swanton, Ohio 43558 USA E-mail: sales@tronair.com
Website: www.tronair.com

### 1.4 SPECIFICATIONS

Aircraft Application	Premier manufactured by Raytheon
Max Aircraft Gross Weigh	12,500 lbs (5.6 Metric ton)
Extended Length	101 in (256.54 cm) from eyebolt centerline to aircraft attachment centerline
Collapsed Length	65-1/8 in (165.42 cm) from eyebolt centerline to aircraft attachment centerline
Width	15-1/8 in (38.42 cm)
Height	3 in (7.62 cm)
Weight	40 lbs (18.14 kg)
Finish	Blue Powder Coat

### 2.0 SAFETY INFORMATION

### 2.1 GENERAL

The Tronair Model 01-1286-0000 Snap-Bak Towbar is used for moving the Premier Aircraft only.

To ensure safe operation, please read the following statements and understand their meaning. This manual contains safety precautions which are explained as follows. Please read carefully.



### WARNING!

Warning is used to indicate the presence of a hazard that can cause **severe personal injury, death, and/or substantial property damage** if the Warning Notice is ignored.

### **CAUTION!**

Caution is used to indicate the presence of a hazard, which will or can cause *minor personal injury or property damage* is the Caution Notice is ignored.



### **WARNING!**

A damaged or bent towbar should not be used. Towbar should be repaired or replaced.



#### 3.0 **TRAINING**

#### 3.1 TRAINING REQUIREMENTS

The employer of the operator is responsible for providing a training program sufficient for the safe operation of the towbar.

#### 3.2 TRAINING PROGRAM

The employer provided operator training program should cover safety procedures concerning use of the towbar in and around the Premier at the servicing location.

#### **OPERATOR TRAINING** 3.3

The operator training should provide the required training for safe operation of the towbar.

NOTE: Maintenance and Trouble Shooting are to be performed by the skilled and trained technician.

#### 4.0 **OPERATION**

#### 4.1 TOWBAR CHECKLIST

#### 4.1.1 Towbar

- Check weld between lunette and tube for cracks.
- Check lunette for bending, excessive wear and deformity.
- Check weld between tube and spring retainer for cracks.

#### 4.1.2 **Towing Head**

- Check welds between side rails and head rail for cracks.
- Check welds between head rail and spring retainer housing for cracks.
- Check welds between side rails and stationary pin. Also sliding pin wear sleeve for cracks.
- Check fastener connection of towing head to towbar. Ensure the connection is not loose or missing.
- Check sliding pin ball lok-T pin. Ensure ball lok-T pin is securely attached to the side rail via its lanyard. Ensure ball lok-T pin is not missing.
- Check sliding pin for bending or excessive wear. Ensure sliding pin slides freely.
- Check sliding pin roll pin. Ensure roll pin is not loose or missing.
- Check snap-bak spring. Ensure the spring is not loose or taken a set. Ensure the spring operates correctly.



### WARNING!

A damaged or bent towbar should not be used. Towbar should be repaired or replaced.

#### 4.2 **USAGE PROCEDURE**

#### 4.2.1 Aircraft Attachment



### **CAUTION!**

It is recommended that your towbar be attached to the aircraft first, and then connected to the tug to avoid possible aircraft damage.

#### 4.2.2 Tug Attachment

Use a pintle height so that the towbar is as level as possible during towing. Also, the pintle hook height should prevent contact of the towbar with the ground during towing.



### CAUTION!

Damage to the towbar or aircraft can result from an excessive towbar angle during towing operations. Reference Figure 1.





Figure 1

Correct

Incorrect Fycassiva Towhar Angla





### 4.2.3 Couplers



### **CAUTION!**

Damage to the towbar or aircraft can result while towing with the following types of couplers:

- Lift Head
- Standard Duty Latch
- Vertical Side Swing Latch
- Swivel Hook

The couplers listed above are known to cause binding and failure in the eyebolt. Indicators of binding are wear on outside diameter of the eyebolt and indentation on the inside diameter of the eyebolt. *Reference Figure 2*.





Figure 2




01-1950-5000 Standard Telecoupler

Tronair recommends a telecoupler pintle hook arrangement. This arrangement is known to eliminate binding. Tronair offers a Standard Telecoupler, Model Number 01-1950-5000, for use on tugs. *Reference Figure 3.* 


Damage to the towbar and/or aircraft can result by towing or pushing an aircraft with an incorrect size eyebolt or pintle pin. A correct size eyebolt will make contact with the pintle pin. A gap between the eyebolt outside diameter and the coupler face plate should be easily seen. An eyebolt which is too large will cause the eyebolt to make contact with the face plate of the coupler. When the eyebolt is too large for the coupler, a gap between the inside diameter of the eyebolt and the coupler face plate will be seen. *Reference Figure 4.* 

To ensure proper towing and pushing, check to make sure the pintle pin diameter is not too long for the eyebolt's inside diameter. An approximate one-half inch ( $\frac{1}{2}$ ") gap between the pin diameter and the eyebolt should be seen. If any of these conditions are not met, please contact Tronair for information to obtain a new coupler.



### 4.2.4 Towing Operation

Damage to the towbar or aircraft can result from pushing an aircraft while maintaining too sharp of an angle between the tug and the aircraft. Contact between the towbar weldment and the tug must be avoided. It is recommended that the angle between the tug and towbar not exceed 90°. *Reference Figure 5* 







### 5.0 PROVISION OF SPARES

### 5.1 SOURCE OF SPARE PARTS

Spare parts may be obtained from the manufacturer:

**TRONAIR**, Inc. Telephone: (419) 866-6301 or 800-426-6301

1 Air Cargo Pkwy East Fax: (419) 867-0634 Swanton, Ohio 43558 USA E-mail: sales@tronair.com Website: www.tronair.com

For Spare Parts, Operations & Service Manuals or Service Needs: Scan the QR code or visit Tronair.com/aftermarket

### 5.2 RECOMMENDED SPARE PARTS LISTS

Reference the following page(s) for Replacement Parts and Kits available.

Recommended Spares to be kept on hand:
K-1205......Kit, Sliding Pin Replacement
K-1308.....Kit, Ball Lok-T Pin Replacement
K-1337.....Kit, Ball Lok-T Pin Replacement
K-3147.....Kit, Pivot Bolt Replacement



Contact Tronair, Inc. for technical services and information. See Section 1.3 - Manufacturer.

### 7.0 GUARANTEES/LIMITATION OF LIABILITY

Tronair products are warranted to be free of manufacturing or material defects for a period of one year after shipment to the original customer. This is solely limited to the repair or replacement of defective components. This warranty does not cover the following items:

- a) Parts required for normal maintenance
- b) Parts covered by a component manufacturers warranty
- c) Replacement parts have a 90-day warranty from date of shipment

If you have a problem that may require service, contact Tronair immediately. Do not attempt to repair or disassemble a product without first contacting Tronair, any action may affect warranty coverage. When you contact Tronair be prepared to provide the following information:

- a) Product Model Number
- b) Product Serial Number
- Description of the problem

If warranty coverage is approved, either replacement parts will be sent or the product will have to be returned to Tronair for repairs. If the product is to be returned, a Return Material Authorization (RMA) number will be issued for reference purposes on any shipping documents. Failure to obtain a RMA in advance of returning an item will result in a service fee. A decision on the extent of warranty coverage on returned products is reserved pending inspection at Tronair. Any shipments to Tronair must be shipped freight prepaid. Freight costs on shipments to customers will be paid by Tronair on any warranty claims only. Any unauthorized modification of the Tronair products or use of the Tronair products in violation of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied.


The obligations of Tronair expressly stated herein are in lieu of all other warranties or conditions expressed or implied. Any unauthorized modification of the Tronair products or use of the Tronair products in violations of cautions and warnings in any manual (including updates) or safety bulletins published or delivered by Tronair will immediately void any warranty, express or implied and Tronair disclaims any and all liability for injury (WITHOUT LIMITATION and including DEATH), loss or damage arising from or relating to such misuse.

### 8.0 APPENDICES

APPENDIX I Declaration of Conformity



Parts List
When ordering replacement parts/kits, please specify model, serial number and color of your unit.



Item	Part Number	Description	Qty
1	Z-4646-01	Weldment, Outer Tube	1
2	Z-4647-01	Weldment, Inner Tube	1
3	G-1155-106222	Screw, Hex Socket Head Shoulder, 5/16 -18, 3/8" diameter x 2 1/4" long	1
4	TR-1672-01	Sleeve	1
5	G-1250-1060N	Flatwasher, <sup>5</sup> / <sub>16</sub> Narrow	1
6	G-1202-1060	ESN, 5/16 -18	1
7	H-1232	Spring	1
8	Z-1736-01	Weldment, Head Not Sold Sepa	rately
9	G-1300-19040	Pin, Roll, <sup>3</sup> / <sub>16</sub> " diameter x ½" long	1
10	G-1310-0415	Pin, Ball Lok-T, ¼" diameter x 1 ½" long	1
11	R-1155	Pin, Sliding	1
12	H-1026*07.0	Assembly, Lanyard	2
13	G-1351-04	Rivet, <sup>1</sup> / <sub>8</sub> Open End	2
14	G-1310-0525	Pin, Ball Lok-T, 5/16" diameter x 2 1/2" long	1



Parts List
When ordering replacement parts/kits, please specify model, serial number and color of your unit.

Item	Part Number	Description	Qty	
	K-1205	Kit, Sliding Pin Replacement; consists of:		
9	G-1300-19040	Pin, Roll, <sup>3</sup> / <sub>16</sub> " diameter x ½" long	1	
11	R-1155	Pin, Sliding	1	
	K-1308 Kit, Ball Lok-T Pin Replacement; consists of:			
10	G-1310-0415	Pin, Ball Lok-T, ¼" diameter x 1 ½" long	1	
12	H-1026*07.0	Assembly, Lanyard	2	
13	G-1351-04	Rivet, <sup>1</sup> / <sub>8</sub> Open End	2	
	K-1337	Kit, Ball Lok-T Pin Replacement; consists of:		
12	H-1026*07.0	Assembly, Lanyard	2	
13	G-1351-04	Rivet, <sup>1</sup> / <sub>8</sub> Open End	2	
14	G-1310-0525	Pin, Ball Lok-T, 5/16" diameter x 2 1/2" long	1	
	K-3147	Kit, Pivot Bolt Replacement; consists of:		
3	G-1155-106222	Screw, Hex Socket Head Shoulder, 5/16 -18, 3/8" diameter x 2 1/4" long	1	
4	TR-1672-01	Sleeve	1	
5	G-1250-1060N	Flatwasher, 5/16 Narrow		
6	G-1202-1060	ESN, <sup>5</sup> / <sub>16</sub> -18	1	



# **APPENDIX I**

**Declaration of Conformity** 



## **DECLARATION of CONFORMITY**

The design, development and manufacture is in accordance with European Community guidelines

Portable Snap-Bak Towbar 01-1286-0000

Relevant provisions complied with by the machinery: 2006/42/EC

Relevant standards complied with by the machinery: EN ISO 12100-1

Identification of person empowered to sign on behalf of the Manufacturer:

Quality Assurance Representative

Phone: (419) 866-6301 | 800-426-6301

Web: www.tronair.com

Email: sales@tronair.com