

Operation & Service Manual



06-5052-3600 Hydraulic Service Unit

12/2004 - Rev. OR

Includes Illustrated Parts Lists

TABLE OF CONTENTS

			PAGE
1.0	General De	escription	1
2.0	Specification	ons	1
3.0	Features		1
4.0	Preparation	n For Use	1
5.0	Operation .		1
	5.1 Hvc	draulic Service Unit Operation	1
	5.2 Cor	nponent Testing	1
6.0	Parts List		1
	ENDIX I ENDIX II	HC-1035 Hydraulic Hand Pump (Phosphate Ester) Parts List Instrument Certification Notice	

REVISION DATE TEXT AFFECTED OR 12/2004 Original Release

This product can not be modified without the written approval of Tronair, Inc. Any modifications done without written approval voids all warranties and releases Tronair, Inc., its suppliers, distributors, employees, or financial institutions from any liability from consequences that may occur. Only Tronair OEM replacement parts shall be used.

1.0 GENERAL DESCRIPTION

The Tronair Hydraulic Service Unit (HSU) is a compact unit designed to provide a source of clean, pressurized fluid for filling reservoirs; bleeding brakes and other maintenance functions.

2.0 SPECIFICATIONS

Tank Capacity:8 gallonMaximum Pressure:500/4000 psigFluid:Phosphate Ester

Filtration: 2 Micron **Weight:** 65 lbs

3.0 FEATURES

- 15 foot hoses
- Pressure gauge
- Shut-off valve for component testing
- 4,000 psi high/low pump provides high flow and high pressure capability.
- Four-way valve for testing double acting cylinder
- Quick disconnects

4.0 PREPARATION FOR USE

The HSU is shipped fully assembled and only the following steps are required to make the unit operational:

- 1. Apply appropriate fluid label on reservoir near fill opening. (See Illustrated Parts List.)
- 2. Service reservoir fill reservoir with appropriate clean fluid.
- 3. Adjust handle height to suit.

Remove Air from Hydraulic Service Unit System by:

- 1. Close manual pump release screw (lower right corner of pump base block).
- 2. Open shut-off valve (adjacent to pressure gauge).
- 3. Move pump handle to top of stroke.
- 4. Remove pipe plug located near top side of piston cylinder.
- 5. Lower handle until there is fluid filling (spilling out) the top cavity.
- 6. Re-install pipe plug.
- 7. Flow fluid by actuating manual pump.

5.0 OPERATION

5.1 HYDRAULIC SERVICE UNIT OPERATION

- 1. Securely attach hose(s) to the aircraft.
- 2. Close pump release screw.
- 3. Open shut-off valve.
- 4. Select output hose #1 or #2 by rotating handle pointer to selected hose.
- 5. Transfer hydraulic fluid by actuating the manual hydraulic pump.

When Service Has Been Completed:

- 1. Open pump release screw to relieve hydraulic pressure.
- 2. Disconnect hose(s) from aircraft.

Install dust plug.

5.2 COMPONENT TESTING

A shut-off valve has been provided to assure no back flow of fluid and therefore is to be closed after the required pressure has built up in the system.


Pressure is relieved by opening this shut-off valve and pump release screw.

6.0 PARTS LIST

Reference following pages for ordering information of Replacement Parts and Kits.

Parts List


Hydraulic Service Unit
When ordering replacement parts/kits, please specify model, serial number and color of your unit.



ITEM	PART NUMBER	DESCRIPTION	QTY
1	HC-1084 (See Page 4)		sphate Ester)1
	Z-1201-02		
3	H-1802	Tank	
4	U-1001-01	Wheel	2
5	Z-1083-01	Handle, Unit	1
6	HC-1042	Gauge, Pressure	1
7	HC-1101-02 (See Page 5)	Valve, Shut Off (Phosphate Est	<i>fer)</i> 1

Parts List


Hydraulic Service Unit
When ordering replacement parts/kits, please specify model, serial number and color of your unit.



ITEM	PART NUMBER	DESCRIPTION	QTY
9	HC-1046-01	Valve, Selector	1
10	HC-1030	Breather	1
		Handle, Pump	
13	V-1100	Label - Fluid Type	
		Hose, Pump Suction	
		Hose, Valve Return	
		Assembly, Hose	
		Coupling, Q.D	
		Plug, Dust	
8	K-2466-02	Kit, Pump Replacement; consists	of:
	HC-1035	Pump, 2 Stage Hydraulic (Phosphai	te Ester)1
	INS-1334	Instruction, Pump Replacement	1
		Hose	

Parts List


HC-1084 Pressure Filter (4 inch) Assembly When ordering replacement parts/kits, please specify model, serial number and color of your unit.



ITEM	PART NUMBER	DESCRIPTION	QTY
1	HC-1084	Assembly, Pressure Filter (Phospl	hate Ester)1
2	K-1415	Kit, Filter Element; consists of:	
	HC-1417	Element, Filter (Phosphate Ester).	1
		O-Ring, Series 2	
		O-Ring, Bowl (Phosphate Ester)	

Parts List HC-1101-02 Shut-Off Valve

When ordering replacement parts/kits, please specify model, serial number and color of your unit.



ITEM	PART NUMBER	DESCRIPTION	QTY
(Complete Component)	HC-1101-02	Assembly, Valve (Phosphate Ester)	1
2		Handle. Valve	
3		O-ring (Phosphate Ester)	



APPENDIX I

HC-1035 Hand Pump Parts List



HC-1035 Hydraulic Hand Pump

Parts List With Illustrations

08/1998 - Rev. 04

When ordering replacement parts/kits, please specify model, serial number and color of your unit.

Phone: (419) 866-6301

Fax: (419) 867-0634

800-426-6301

HC-1035 Hydraulic Hand Pump

Parts List

This pump is compatible with Phosphate Ester Hydraulic Fluids.

Reference Parts List Illustration on following page.


ITEM	PART NUMBER	DESCRIPTION	QTY.
1	501-000	Pump Body	1
		Bushing – 3/8 x 3/8 NPT	
8	508-000	Pivot	1
		Pin Assembly	
		Bracket - Pump Handle	
		Handle	
		Handle Grip	
		Strap	
		Plug	
		Spring - Outlet Plug (L.P.)	
		Piston - Bypass	
		Valve Body	
		Ball - Bypass	
		Retainer Plate	
		Piston - High Pressure	
		Piston - Low Pressure	
		Clevis Pin	
		Cotter Pin	
		Tie Rod	
38	582-125	Flange	1
		Tube - Low Pressure	
40		Plug – 1/16 NPT	
	K-1030	Pump Valve Rebuilt Kit; consists of:	1
16		O-ring - Valve Body	
18		Packing - Piston	
19		O-ring - Guide Shoe	
26		Piston Guide Shoe	
A 1	K-1095	Pump Check Valve Hard Part Kit; consists of:	1
		Ball - Output	Chack
			CHECK
25		,	
	K-1985	Relief Valve Rebuilt Kit; consists of:	1
-			
♦ 6		O-ring - Release Screw	

NOTES:

- 1) Items designated as kits contain all hardware necessary for installation.
- 2) Unless otherwise listed, all replacement bolts should be Grade 5 or better.
- Items that are in more than one kit.



Parts List Illustration







APPENDIX II

DOC-1004 Instrument Certification Notice



Instrument Certification Notice

The gauge Certificates of Calibration supplied for the gauge(s) on this unit contain the calibration data for the actual instrument calibrated, along with the calibration date of the **STANDARD** used to perform the calibration check.

The due date for re-calibration of the instrument should be based upon the date the instrument was placed in service in your facility. Re-calibration should be done on a periodic basis as dictated by the end user's quality system or other overriding requirements.

Note that Tronair, Inc. does not supply certificates of calibration on flow meters or pyrometers unless requested at the time of placed order. These instruments are considered reference indicators only and are not critical to the test(s) being performed on the aircraft.

Phone: (419) 866-6301

Fax: (419) 867-0634

800-426-6301